

# STEP BY STEP GUIDE TO ASSEMBLY


## Step 1



Assemble the upper frame as shown using Tubes 2, 2A & the Side Corner Joints

SIDE  
CORNER  
JOINTS

## Step 2



Assemble the roof section using tubes 1, 1A, 2, 2A and the centre connectors. Attach the roof section to the upper frame using the side joints. Lastly place tube 3 into the remaining outlet of the side corner joint to form the top half of the gazebo leg.

## Step 3



Place the cover tightly over the frame.

### FIRE PRECAUTIONS

This gazebo can burn.  
Do not use naked flames in the gazebo.  
This gazebo has no flame retardant cooking area.


FOR HELP AND ASSISTANCE WITH YOUR PRODUCT PLEASE CALL THE CUSTOMER HELPLINE

TEL: 0151 520 0074. MON-FRI 09:00-16:30

PLEASE STORE INSIDE DURING THE WINTER MONTHS®

# STEP BY STEP GUIDE TO ASSEMBLY

## Step 4




Slot the remaining legs (Tubes 4) into position ensuring the side tube holes are at the base. Push the plastic feet into place.

## Step 5



Pull the leg covers taught and attach the metal hooks into the tube holes near the feet. If the cover becomes loose, tighten by moving the hook to a lower hole. The securing ropes can now be fitted if required.

## Step 6



Hang on all sidepanels, roll up the middle sidepanel if need fresh air, all sidepanels can be hang on or take off separately. To stop water collecting on the roof, eyelets have been added, this will allow water to run off.

### FIRE PRECAUTIONS

This gazebo can burn.  
Do not use naked flames in the gazebo.  
This gazebo has no flame retardant cooking area.

FOR HELP AND ASSISTANCE WITH YOUR PRODUCT PLEASE CALL THE CUSTOMER HELPLINE  
TEL: 0151 520 0074. MON-FRI 09:00-16:30  
PLEASE STORE INSIDE DURING THE WINTER MONTHS